



Philips 3000 Series Sandwich Maker

HD2330/90

- Sandwich Maker

More than just triangular sandwiches

Nonstick grill plates any shape and filling

- Nonstick plates for easy cleanup
- Compact vertical storage saves space in your kitchen
- Indicator lights display when you're ready to toast
- Built-in cord storage for a tidy countertop
- On/off switch for safety and control
- Easy Lock system snaps shut for a tight seal
- 750 W of power toasts to perfection
- Versatile grill plates for sandwiches, paninis, and more

Highlights

Nonstick plates

No more sticking and scrubbing. Wipe clean with ease thanks to the long-lasting nonstick coating on your panini grill plates.

Compact vertical storage

The sandwich toaster stands vertically for convenient storage on your countertop or in the cupboard.

Indicator lights

Lights clearly indicate when your panini maker is warming up and when it's ready to use.

Built-in cord storage

Wrap the cord for orderly storage without cluttering your kitchen.

On/off switch

No need to unplug your sandwich press to turn it on and off.

Easy Lock system

Press sandwiches to perfection every time with a toastie maker that easily snaps open and closed.

750 W of power



Rapid heating toasts everything to crisp, golden perfection in this powerful 750 W panini press sandwich maker.

Versatile grill plates



Make all your favorite toasted sandwiches with any kind of bread on versatile ridged grill plates. ..

Specifications

Technical specifications

Power: 750 W



Publication Date
2024-03-03
Version: 8.8.1
EAN: 8720389032806
www.phillips.com

© 2024 Koninklijke Philips N.V. All rights reserved.
PHILIPS and the Philips Shield Emblem are registered trademarks of
Koninklijke Philips N.V. and are used under license.