



Philips 5000 Series Sandwich Maker

HD2350/80

- Sandwich Maker

Crispy outside, melted inside

3 plate sets for paninis, sandwiches and waffles

- 3 sets of plates for paninis, waffles, and sandwiches
- 750 W of power toasts to perfection
- Removable nonstick plates for easy cleanup
- Even heating for perfect melting and toasting
- On/off switch for safety and control
- Compact vertical storage saves space in your kitchen
- Indicator lights display when you're ready to toast
- Built-in cord storage for a tidy countertop
- Easy Lock system snaps shut for a tight seal
- Cut-and-seal plates keep your fillings inside

Highlights

3 different plate sets

Interchangeable plates make all your favorites from long crunchy paninis to deep-filled sandwiches and waffles, too!

750 W of power

Rapid heating toasts everything to crisp, golden perfection in this powerful 750 W panini press sandwich maker.

Removable nonstick plates

No more sticking and scrubbing. Simple remove the plates and clean with ease thanks to the long-lasting nonstick coating.

Even heating

Enjoy sandwiches just how you like them: melted, mouthwatering, perfectly golden brown all over.

On/off switch

No need to unplug your sandwich press to turn it on and off.

Compact vertical storage

The sandwich toaster stands vertically for convenient storage on your countertop or in the cupboard.

Indicator lights

Lights clearly indicate when your panini maker is warming up and when it's ready to use.

Built-in cord storage

Wrap the cord for orderly storage without cluttering your kitchen.

Easy Lock system

Press sandwiches to perfection every time with a toastie maker that easily snaps open and closed.

Specifications

Technical specifications

Power: 750 W



Publication Date
2024-03-03
Version: 7.7.1
EAN: 8720389032813
www.phillips.com

© 2024 Koninklijke Philips N.V. All rights reserved.
PHILIPS and the Philips Shield Emblem are registered trademarks of
Koninklijke Philips N.V. and are used under license.